Manual PL 11 - PLK 13 - PLE 12 with mounting profile



DIAZ SUNPROTECTION

Placement of the clips on the profile

Make sure that the distance between the clip and the end of the pleated blinds is 50 or 65 mm.



Mounting of the pleated blind



Mount the mounting support or mounting angle to a flat surface.



Attach the mounting profile to the mounting support or mounting angle.



Add the sliding blocks to the mounting profile. Use the screw to fit the sliding block into the mounting profile.





Insert the profile in the bottom edge of the clip and press it upwards (untill it clicks).





Please ensure that there is a gap of at least 100 mm between the pleated blind and the glass pane to ensure sufficient ventilation. Furthermore, allowance should be made for ventilation gaps. If the air circulation is inadequate, this may lead to heat accumulation and the formation of condensation. We cannot accept any liability for damage to fabric caused by drip water or insect excrement.

Tension the wire





- 1 Secure the end of the wire by hand or using pliers.
- 2 Release the screw (TX20) slightly (turn anti-clockwise).
- 3 Tension the wire (by hand or use pliers).
- 4 Tighten the screw (turn clockwise).
- 5 Cut off the excess cord ends.



For pleated blinds with more than 1 wire, repeat steps 1 to 4. Do this before starting step 5.

Operation PL 11

The PL 11 system is opened and closed by moving the operating handle, using the control rod if necessary.



Operation PLK 13

The PLK 13 system is opened or closed by turning the crank handle. Attach the crank handle to the crank gear box.



Operation PLE 12

The PLE 12 system is a motorised system. Consult the electric installation instruction for a correct installation.

